

MAINTENANCE INSTRUCTIONS FOR DURAT® SURFACES

When taking a new surface into use it is recommended that the surface is cleaned with a soap based detergent, which is then washed away with water. If needed the new surface can be treated with a thin furniture oil, e.g. Pledge. After the oil has absorbed the surface is washed with a mild soap solution.

DAILY / WEEKLY CARE AND MAINTENANCE

Mild soap based solution	DAILY
Universal detergent for institutional use with a PH of 7-9	DAILY / WEEKLY
Liquid abrasive cream or dishwashing detergent To remove ingrained dirt and small scratches, e.g. <i>CIF</i>	WHEN NEEDED
Window washing spray to remove grease, e.g. <i>CIF</i>	WHEN NEEDED
Using a window washing liquid increases the shine of the surface	WHEN NEEDED

APART FROM USING A NORMAL CLEANING CLOTH A COARSE SPONGE CAN VERY WELL BE USED WHEN CLEANING THE DURAT® SURFACE.

The DURAT® surface withstands most types of detergent. By testing according to the instructions above the most suitable substances for institutional cleaning can be found. Ingrained dirt can be removed from the surface by using machine dishwashing liquids. When necessary the liquid can be left on the surface overnight.

Bigger scratches can be removed by resanding the surface. Sanding papers of water quality are used, e.g. 180, 240 and 400. After the sanding the surface is treated with furniture oil (e.g. JOHNSON, ÅSTRÖM: Liquid Polisher etc.) After the oil has been absorbed into the surface the surface is washed with a mild soap solution.

If you have any questions please do not hesitate to contact the manufacturer.

DURAT®

www.durat.com